

ATTACHMENT 2

SECURITY PROCEDURES

Table of Contents

1.0 Security 1

1.0 Security

Unauthorized and people not aware of facility activities are restricted from entering the Clean Harbors Clive facility. This is accomplished by utilizing the following provisions: security, surveillance, locked gates, chain-link fence, and warning signs. Security is any person(s) assigned by management to control access into and/or out of the fenced portion of the facility and/or to monitor conditions within the fenced portion of the facility.

- Security: Access into the facility is restricted by the perimeter fence, locked gates, and security. Operation of the main gate is controlled by Clive personnel or other individuals trained in the security procedures of the facility and is opened only to allow shipments of waste or authorized personnel and equipment access in and/or out of the facility. The main gate will remain closed at all other times.
- Surveillance: Security conducts surveillance of the facility at least once each day. This surveillance will be documented in the security log book. Area lighting aids security in monitoring the facility. Exterior area lights are on at nights.
- Fence: The facility is completely surrounded by a chain link fence with gates. The fence, including the barbed wire at the top, is at least six feet high. The main gate is the primary route for entrance and exit from the facility. Secondary entrance and exit routes for the facility are through the other gates in the perimeter fence. There are three secondary gates which may be opened only from the inside when necessary for evacuation or maintenance activities. Five additional secondary gates are used only for maintenance activities and are padlocked shut. Clive personnel or other individuals trained in the security procedures of the facility, control gate access to the facility. Wastes enter the facility through the main gate and the rail access gate.

If there is a power failure, security can operate the main gate manually. The secondary gates, which are designated as evacuation exits, are equipped with a magnetic lock and/or a chain and padlock. The magnetic locks are unlocked by a push button which is located inside the fence near the gate or by activation of the evacuation alarm. The magnetic locks are powered through an uninterruptible power supply. The key for the padlock is located in a key box which is located inside the fence near the gate.

During emergency conditions, site personnel or other individuals trained in the security procedures of the facility restrict entry into and/or aid personnel in exiting the facility as required by the Emergency Coordinator.

Anyone inside the facility can open a secondary gate that has been designated as an evacuation exit and leave. This is necessary so that personnel can exit the facility if required during an emergency. Persons who need to exit through one of the secondary

gates, other than for an emergency, will notify security by telephone, radio, or in person. These gates will either be monitored or shut and locked after the person(s) exits the gate.

- Warning signs: All gates have a warning sign attached. The signs, written in English, read: "DANGER - UNAUTHORIZED PERSONNEL KEEP OUT." These signs are legible from a distance of at least twenty-five feet. The warning signs are placed at least every ten fence posts, about 100 feet apart, along the perimeter fence so as to be seen from any approach to the active portion of the facility.